

## XTI FLANGE FIXED RECESSED



## installation instruction


- 1 IP Power entry
- 2 Profile (side view)
- 3 End plate
- 4 Support structure
- Fasteners (not supplied)
- 6 Recessed flange








## **Determine** mounting **location**

2









## WARNING

**AUSTRALIA** 

HONG KONG

- 1. Luminaires are not site serviceable they must be returned to your local Xero factory for servicing. Opening luminiaires or modifying them in any way voids the warranty
- **2.** Luminaires must not be terminated in direct sunlight they must be installed in a semi-outdoor environment (undercover) as thermal expansion cannot be controlled in direct sunlight
- 3. The feed cable MUST be installed in an IP rated enclosure equivalent to the IP rating of the luminaire or warranty is VOID
- 4. Maximum circuit power is 10a unless otherwise stated it is imperative that Luminaires are not wired together in such a way as to exceed the maximum total circuit power)
- 5. Xero luminaires are designed for commercial environments only and are not suitable for household or personal use.
- 6. The light source contained in this luminaire is non-user replaceable. It shall only be replaced by Xero Lighting.

If more information is required please contact you local representative by going to xerolighting.com/contact. Or you can email us at headoffice@xerolighting.com

**MALAYSIA** 



UNITED KINGDOM **UNITED STATES** 

**NEW ZEALAND** 

**SINGAPORE** 

UAE